

DIY

LAUNDRY WALL CABINETS

SUPPLY LIST PLUS STEP-BY-STEP

Instruction



Laundry Wall Cabinets

Supply list:

- 2-1x12x8
- 2-1x3x8
- Kreg jig
- 1 1/2" pocket hole screws
- Wood glue
- Paint
- Paintbrush
- 4 hinges
- Stud finder
- Drill
- 4x4 1/4" plywood
- 1" finishing nails
- Miter saw
- Chalkboard spray paint
- Ear & eye protection
- Sander
- Level
- 2" drywall screws

Cut list:

5-1x12 @ 24"

4-1x3 @ 24"

4-1x3 @ 7.5"

1/4" plywood @ 24" x 24" (cabinet back)

2- 1/4" plywood @ 12.5" x 24"

Step 1:

Make all necessary cuts.



Laundry Wall Cabinets

Step 2:

Drill 3 pocket holes on each side into 3 of the 1x12 pieces. Drill 2 pocket holes on each side of the long 1x3 pieces.

Step 3:

Attach the 1x12 pieces with 1 1/2" pocket hole screws creating a box.

Step 4:

Measure up halfway, this is where you'll add the middle shelf. Then attach the shelf with 1 1/2" pocket hole screws.



Laundry Wall Cabinets

Step 5:

Assemble the doors with wood glue and by attaching 1 1/2" pocket hole screws.



Step 6:

Spray paint the pieces of plywood with the chalkboard paint. Allow them to dry for about an hour.

Laundry Wall Cabinets

Step 7:

Attach the back of the cupboard with 1" finishing nails and the remaining piece of plywood.

Step 8:

Paint the door frames and cabinet with paint.
Allow them to dry for at least 2 hours.

Step 9:

Attach the chalkboard plywood to the door frames with 1" finishing nails.

Step 10:

Attach the doors to the cabinet with the hinges.



Laundry Wall Cabinets

Step 11:

Find the studs on the wall you're going to hang the cabinet.

Step 12:

Using the drywall screws, attach the cabinet to the wall.

Step 13:

Add your stuff to your cabinet and enjoy an organized space!

