

DIY

LAUNDRY STORAGE CART ON WHEELS

SUPPLY LIST PLUS STEP-BY-STEP

Instruction



Laundry Storage Cart

Supply list:

- 2'x4' 1/2" plywood
- 1x10x6
- 1x3x8
- 4 Wheels
- Washers & screws
- Cupboard hardware
- White paint
- Kreg jig
- 1 1/2" pocket hole screws
- Wood glue
- Drill
- 1 1/2" finishing nails
- Paintbrush
- Sander
- Saw (miter and jig)
- Tape measure
- Level
- Pencil
- Hammer
- Eye and ear safety gear

Cut list:

2-1x10 @ 36"

6-1x3 @ 17"

3-1/2" Plywood @ 16" x 10"

Step 1:

Make all necessary cuts.



Laundry Storage Cart

Step 2:

Drill pocket holes into the plywood pieces.

Step 3:

Attach the top piece to the front and back pieces (1x10 pieces).

Repeat this process for the bottom.

Step 4:

Make a mark at the halfway point on the 1x10 (both pieces) this is where you'll attach the last piece of plywood. This will be your middle shelf.

Step 5:

Using the finishing nails, attach the 1x3's about 8" above the base and 4" above the middle shelf.



Laundry Storage Cart



Step 6:

Attach the wheels using nuts and screws to the bottom of the cart.



Laundry Storage Cart

Step 7:

Using a sander, sand down the entire cart. Make sure there are no raw edges.

Step 8:

Paint the cart. Then allow the cart to dry for at least 2 hours.

Step 9:

Attach the cupboard hardware.
Drill pilot holes before attaching the hardware.



Step 10:

Add your desired items to your storage cart!

