

OVER THE

TOILET SHELF

SUPPLY & CUT LIST PLUS STEP-BY-STEP

Instruction



Over the toilet shelf instructions

Supply list:

- 2' (or 4') 3/4" dowel
- 2-1x3x8
- 1-1x8x4
- 1-1x6x4
- 2" wood screws
- Wood glue
- Miter saw
- Drill & countersink drill bit
- Stain
- 3/4" drill bit
- Paintbrush or rag
- Level
- Sander
- 80 grit sandpaper
- Wood filler
- Gloves, eye & ear protection, mask, & pencil

Cut list:

1x8 @ 20" (lg. shelf)
1x6 @ 20" (sm. shelf)
1x3 @ 21.5" (top support)
2-1x3 @ 26" (angle sides)
2-1x3 @ 20" (shelf backs)
2-1x3 @ 6" (sm. shelf sides)
2-1x3 @ 8" (lg. shelf sides)
3/4" dowel 24"

Step 1:

Make all of your cuts. This makes the building process go by quicker.
Try labeling them so you don't forget where each piece goes.



Over the toilet shelf instructions

Step 2:

Attach the top support piece to the angled side pieces (we will be angling them later) with 1 screw on each side. Make sure to pre-drill your screw holes so the wood won't crack. (I did not use wood glue because I knew I'd be moving them into place later.)

Step 3:

Assemble both shelves. Use wood glue and wood screws to assure a strong hold.



Step 4:

Attach the shelves to the shelving frame. Determine how far apart you'd like each shelf then attach each shelf with one screw on each side. This way you can adjust the angle so your shelves are level.

See the photo on the next page to see how I created the angle.

Over the toilet shelf instructions



Step 5:

Make sure each shelf is level and attach the shelves with a second screw on each side.



Over the toilet shelf instructions

Step 6:

Attach the dowel. Sorry I don't have a picture of that process. Use a 3/4" drill bit to add holes to each side of the bottom to attach the dowel. You can have the dowel stick out on each side to give it a different look. Make sure to use wood glue in the process. This is what's going to hold it in place.

Step 7:

Fill all of the holes with wood filler. Then allow to dry for about 2 hours.



Step 7:

Sanding time! Remove all imperfections, wood stamps, rough edges, and excess wood filler. Once the shelf has been sanded, you'll want to wipe it down so there's no excess saw dust.



Over the toilet shelf instructions



Step 8:

It's time to stain. I used a stain poly mix so this was just one step. Allow the stain to dry overnight.

