

DIY RUSTIC

FARMHOUSE CENTERPIECE

SUPPLY LIST PLUS STEP-BY-STEP

Instruction



Rustic Farmhouse Centerpiece

Supply list:

- 1x6x6 cedar plank
- 1/4" 6x6 craft board
- 1x3x1
- wood glue
- finishing nails
- sandpaper
- saw
- stain
- paintbrush
- safety equipment

Cut list:

Cedar plank:

2 @ 12"

2 @ 5.5"

Craft board at 13"

1x2 @ 12"

Step 1:

Make all necessary cuts.

Step 2:

Assemble box by attaching the 5.5" cedar planks to the 12" cedar planks. I found starting the nails in the 5.5" board made the process easier. This way everything stayed flush.



Rustic Farmhouse Centerpiece



Step 3:

Attach the 1x3 to the 1x6 craft board. Use wood glue and nails for this process. Make sure the 1x3 is centered so this will fit.

Step 4:

Attach the bottom to the box using wood glue and finishing nails.

Step 5:

Sand your entire box. Make sure that all of the edges are smooth and there are no stray pieces. I found that the cedar likes to crumble so make sure you don't skip this step.



Rustic Farmhouse Centerpiece

Step 6:

Stain the planter box. Then allow the planter box to dry overnight. I use a stain poly mix so I'm able to skip the poly step. If you're using straight stain then you'll want to add a coat of poly a couple of hours after you apply the stain.

Step 7:

Add 3-pint size mason jars filled 3/4 of the way with water.

Step 8:

Add your fresh cut flower to this planter and you're done!

